

One-Loft-Race

Version 3.02



Instruction

**Motz-Computer
Service und Vertriebs GmbH
Pfennigbreite 20 – 22
D-37671 Hörter**

Index

Licence Code	3
Program	3
Input tribe data	4
Input tribe data function	4
New	4
Edit	5
Delete	5
Activate Antenna.....	5
Allocate	5
Delete Ring.....	6
Search	6
Print	6
Entry In.....	6
Registration	7
Race registration.....	7
Training	7
Race Plan.....	8
Home coordenates input.....	8
Set PC-Time	8
Print registration Line.....	9
Online Report	9
Internetupload.....	10
Online Report	10
Points / Price.....	10
Language	10
COM-Port.....	11
Number of price pigeon.....	11
Metrisch.....	11
System	11
Neutral Time	11
Extra	11
Printer Linking	11
Import	11
Exort.....	11
Write Pigeon to Breeder.....	12
Calculate Aspoints / Time List.....	12
Training	12
Open Tainingsdata / Save Trainingsdata.....	12

Licence Code



Input the licence code. When you don't input the licence the software running in Demo-Mode. In this mode you can input only 10 Pigeon.

Program



The Menu "Program" are the Mainpoint. At this point you can input all necessary settings and data.

Input tribe data

Name	Adress	Country	payed
------	--------	---------	-------

Number	Name	El-ID	descent	Farbe	Gruppe
--------	------	-------	---------	-------	--------

Total Breeders: 0 Total pigeons: 0 Total unallocation pigeons: 0 Total Pigeon of Breeder: 0 Allocate pigeon: 0

At this Menu you can input the Fancier and Pigeon Data. When you have input all information you can Allocate the pigeon.

Input tribe data function



When you go with the mouse over the Points, you become a short information about this Function.

New

At this point you can input fancier or pigeon data. You can only input Pigeon data when you have input first the Fancier data. When you have input the fancier data you can mark this and switch with the mouse in the Pigeon area. At this you can input the Pigeon.

New breeder

Breeder data

Name:

Adress:

Country:

payed

OK

Cancel

At the field “Name” you can input the Fancier-Name or the Team-Name. This Name will be print at all result lists. In the field “Adress” you can input the adress of the Fancier or Team. This is only for your information. At the field “Country” you can select the Home-Country of the Fancier or Team. This will be needed for the “Online-Portal”. The point “payed” is for your information. You can select it when the Fancier or Team have payed.



At the field “Number” you can input the Pigeon-Number. The field “Name” are only for additional Information. The same are for the “Color”. At the field “Group” you can input a number. When you input the same number at different pigeon they are in the same group.

The point “Descent” are for the Parentage. You can scan the Parentage and select this file to the pigeon.

Edit

Here you can change the Fancier information or the Pigeon information.

Delete

Here you can delete the Fancier information of the Pigeon information.

Activate Antenna

At this Point you can activate the System for registration or allocation. When you push the button a message ask you to start the system. The system you can start when you power up. When you use a MC2100 with BUS-Antennas they show you how many Traps connected and which serial number they have.

Allocate

When the System are running and you put a electronic ring over the trap the number will show at the MC2100 on the left. When you push the button the electronic number will transmit to the selected Pigeon. Please note that you don´t must transmit any information to the MC2100.

When you are finish with the allocation you must delete the MC2100. For this go to the point “Delete” at the MC2100 and input the delete code. Standard is 123456.

Delete Ring

Here you can delete the electronic number at the selected pigeon. You can use it when you have made a mistake.

Search


At his point you can search for a Fancier or for a Pigeon.

Print


You can Print the allocation list. Sorted by fancier or by pigeon.

Entry In

When you will make a official race you must first basketing the pigeon. Only basketing pigeon are registrated. For basketing you must input first a race "Race Plan".



Select the Race first which you will basketing. At "Number of price pigeons" you can set how many pigeon make prices for this race. You can input it in % or how many of the basketing pigeon. When you select "Printout with Points" the system calculate the points for this race automaticly.



For basketing this race you must activate the system. After this you can put the pigeon over the normal antenna one by one. The software switch the information and shows you how many pigeon are basketing. At the button print you can print a basketing list. At the button “Reset race data” you can delete the complete basketing.

When you are finish with basketing you must delete the MC2100. For this go to the point “Delete” at the MC2100 and input the delete code. Standard is 123456.

Registration

Here you can select a Training Race or a official Race. You can print the result when you push the print button. It shows you the print list first on you screen. This list you can export in the “HTML” file.

Race registration

For this Race you must basketing first the pigeon. You must select the race and after this activate the system.

When the race are finish you must delete the MC2100. For this go to the point “Delete” at the MC2100 and input the delete code. Standard is 123456.

Training

The Training Race you can made every time without basketing. You can input the race information when you want. The system need it to calculate the speed.

When the Training race are finish you must delete the MC2100. For this go to the point “Delete” at the MC2100 and input the delete code. Standard is 123456.

Race Plan

The 'New Race' dialog box is divided into two main sections. The top section, 'Liberation data', includes a text field for 'Place', a date picker set to '15.08.2011', a time spinner set to '00:00:00', and a text field for 'Lowest speed'. The bottom section, 'Coordinates', features three radio buttons: 'Longitude', 'Latitude', and 'Distance (m)'. Each radio button is followed by three input boxes for degrees, minutes, and seconds. The 'Distance (m)' field has a single input box with the value 0. 'OK' and 'Cancel' buttons are located on the right side of the dialog.

The Race Plan you need for all official races. Input for this the Name of the Race. The starting date and time. The Lowest speed calculate automatically after the race. For the distance you can input the coordinates or the meter.

Home coordinates input

The 'Home Coordinates' dialog box features a section titled 'Coordinates' with two radio buttons: 'Longitude' and 'Latitude'. Each radio button is followed by three input boxes for degrees, minutes, and seconds. The 'Longitude' field has a blue cursor in the first box. 'OK' and 'Cancel' buttons are located on the right side of the dialog.

When you only work with Coordinates you must input here the coordinates of the home Loft.


Set PC-Time

Here you can set the Computer Time. With this time the MC2100 will set at every startup.

Print registration Line

When you have connected a Line Printer at your computer and activate this function. The printer print every pigeon when the system registrate a pigeon.

Online Report



The screenshot shows a software window titled "One Loft Race Online Report". The window contains several input fields and controls:

- Description:** A section containing four text input fields labeled "Name", "Description", "Contact", and "Live Liste". Below these fields is a URL: `http://www.one-loft-race.de/preisliste.htm`. A "Save" button is located at the bottom right of this section.
- Data they should be transferred:** A section with two checkboxes: "races" and "Training Data". Below each checkbox is a large empty rectangular box.
- Flüge Online Aspunktewertung:** A section with a large empty rectangular box.
- Points / Price:** A section with two radio buttons: "Points" and "Price".
- Buttons:** A "Send Data" button is located at the bottom left, and a "Close" button is at the bottom right.

The Online Report transmit all Race information at the One-Loft-Race Portal.

Please look under <http://www.one-loft-race.de>

When you will use it please contact Tipes under tipes@motz.de for more information.

Settings

Settings

Internetupload

FTP-Server [Adress / IP]
[]

FTP-Starting dir
[]

FTP-User
[]

FTP-Password
[]

FTP-Uploadinterval Geschwindigkeit
10 sec. m/yds Km/Mls

Refresh internet ranking list automaticly

Close Connection after Upload

Don't write Pigeons without a Price in the HTML Page

Language
English

COM-Port
 Com 1 Com 2
 Com 3 Com 4

Excel-Format
RV-Sylt

Number of price pigeons
 33 % Printout with Points
 1 pigeons

Metrisch
 meter yds

System
 Reading Unit MC2100
 Set in over Basketingunit

Neutral time
22:00:00 to 08:00:00

Points / Price
 Points Price Price/Time

OK Cancel

ETIPES
One Loft Race

Internetupload

At this part you must input the Internet FTP settings for the "Live-List". The Software transmit automaticly the live result from the Offical Races or Training Races to the Internet. You can implemented this information to your Website. For more information please ask your provider.

Online Report

Here you can input the Licence Code for the One-Loft-Race Portal.

Points / Price

Here you can select the calculation of the Points. The system need this when you will calculate the Points over more races.

Language

Select the Language of the software. After change you must start the program again.

COM-Port

Here you can select the com port where you have connected the MC2100. When you have a computer without a com port you can use a usb to serial converter.

Number of price pigeon

At “Number of price pigeons” you can set how many pigeon make prices for this race. You can input it in % or how many of the basketing pigeon. When you select “Printout with Points” the system calculate the points for this race automaticly.

Metrisch

Select the distance in meter or yards.


System

Select the system which you use. The MC2100 or the older one with the reading unit. The point basketing unit you only need when you made a FCI RACE. For this you must basketing the pigeon over the Master unit and not over the normal Antenna.

Neutral Time

Input here the “Neutral Time” All Pigeon they are registrated in this time area will set in this case to 08:00.

Extra



Printer Linking

Not Supported. Only for internal Tests.

Import

You can import the fancier and pigeon information from a .csv format

Exort

You can export the fancier and pigeon information in a .csv format.

Write Pigeon to Breeder

When you have input a pigeon at a wrong fancier you can switch it to the right fancier with this function.

Calculate Aspoints / Time List

With this function you can calculate Points over more races. You can select the races which you need for the result.

Training



Open Tainingsdata / Save Trainingsdata

When you delete a Traing race the system ask to save the Training race. When you save the races it is possible to open this races later.

Activate Antenna.....	5
activate the system	7
Allocate	4
basketing.....	6, 7
COM-Port.....	11
coordinates.....	8
Coordenates	8
delete code.....	5
Demo-Mode	3
Descent	5
Entry In.....	6
Exort.....	11
export.....	7
Extra	11
Home coordenates input.....	8
Import	11
Input tribe data	4

Input tribe data function.....	4
Internetupload	10
Language.....	11
Licence Code	3
official race	6
One-Loft-Race Portal.....	9
Online Report.....	9, 10
Points / Price	10
Print registration Line	9
Printout with Points	6
Program.....	3
Race Plan	8
Reset race data	7
Set PC-Time.....	8
Settings	10
Training.....	12
Write Pigeon to Breeder	12